



Partslist FX Verminator MKII

Location	Article number	Description	Location	Article number	Description
1	14023	Bottle cover	A39 - Shp	19057	valvepin Shp
2	0315	Bottle 500cc komplett	A40	2528	O-ring 1,5x1 NBR70
3	14025	Pistolgrip	A43	2525	Spring 0,6x4x15
4	19129	Shroud 247mm		7015	Valvepin complete
4 - Ext	19142	Shroud 449mm		7019	Valvepin Shp complete
A1	5108	O-ring 5,28x1,78 NBR70	A44		Screw M3x18
A2	19029	Pellet probe guide	B1 – 4,5	2529	O-ring 4,3x1,5 NBR70
A3	11509	CPK 3h6x10	B1 – 5,5	11650	O-ring 5,28x1,78 PUR70
A4	5205	Screw M4x20	B1– 6,35	4526	O-ring 6,35x1,27 NBR70
A5	1511	Rubberseal washer	B2	5112	O-ring 5,28x1,78 NBR70
A6	14015	Plastic washer 2x6,8	B3 – 4,5	2057	Barrel inlet .177
A7	14008	Air bottle connector	B3 – 5,5	2056	Barrel inlet .22
A8	11541	Hammerspring adjuster HP	B3 – 6,35	19104	Barrel inlet .25
A9	11030	Hammerspring adjuster	C1	19164	Copper pipe
A10	5206	8x14x0.25 steel washer	C2	19135	Rubber steel disc
A11	11500	Hammer spring	C3	19163	Copper pipe
A12	11540	Hammer weight v7	D1	11503	Spring 0,5x2,5x4,4
A13 - 4,5	19013	Black plastic bushing 4,5	D2	11527	Steelball 3,175
A13 - 5,5	19012	Black plastic bushing 5,5	D3	11633	Grubscrew M2,5x8
A13 - 6,35	19101	Black plastic bushing 6,35	D4	11508	Grubscrew M3x8
A14	19039	Hammer v7	D5	11027	Safety axel
A15	19031	M3 Special screw v7	D6	11625	Safety pin
A16	2534	Grubscrew M5x6 with tip	D7	11200	Safety knob
A17	19086	Grubscrew M6x8	E1	19021	Sidelever linkage v7
A18	2503	Grubscrew M5x8	E2	19042	CPK 2m6x8
A19 EXT	19143	Barrelswitching knob	E3 - 4,5	19011	Pelletprobe 4,5 v7
A20	11201	Grubscrew M5x4	E3 - 5,5	19010	Pelletprobe 5,5 v7
A21 EXT	16041	Grubscrew M5x14	E3 – 6,35	19102+19100	Pelletprobe 6,35 v7
A22	2534	Grubscrew M5x6	E4 – 4,5	19171	O-ring 4x2 NBR70
A23	19103	Shroud mount rear	E4 – 5,5	19332	O-ring 5x2 NBR70
A24 - 4,5	19013	Barrel 4,5 285mm	E4 – 6,35		O-ring 6,0x2 NBR70
A24 - 5,5	12006	Barrel 5,5 285mm	E5	19028	CPK 2,5M6x6
A24 - 5,5	12006	Barrel 5,5 485mm	E6	19020	Sidelever v7
A24 - 6,35	19115	Barrel 6,35 485mm	E7	19037	Sidelever handle
A25	5113	O-ring 20,4x2,62 NBR70	F1	19133	Dustcap mkII
A26	19122	Muzzle mkII	F2		O-ring 26,51x3,53 NBR70
A27	19128	Thread protection	F3	19016	Quick connector mkII
A28	19040	CPK 2m6x24	F4	5107	O-ring 2,9x1,78 PUR90
A29	19121	Stock attachment	F5	19005	Quick connect red pin
A30	5108	O-ring 5,28x1,78 NBR70	F6	1511	Rubber steel disc
A31	11505	Manometer 25mm	F7	19132	Alu detail verminator
A32	5005	Plasticwasher 2mm	F8	1511	Rubberseal washer
A33	19038	Spring seat v7	F9	14005	Air cylinder connector
A34	5105	O-ring 9,3x2,4 NBR90	F10	17047	O-ring 11,91x2,62 NBR70
A35	19009	Guide M16	F11	12045	O-ring 13,95x2,62 NBR70
A36 EXT	19043	Regulator	F12	19158	Adapter M20-M12
A37	5111	O-ring 2,5x1,5 NBR90	F13	12046	O-ring 15,88x2,62 NBR90
A38	7044	Valveseat	F14	19056	Connector 1/8" MkII
A38 - shp	19060	Valveseat Shp	F15	12046	O-ring 15,88x2,62 NBR90
A39	19022	Main valve pin	F16	19036	Black plastic seal

